

0116 284 9900 | Orders@oem.co.uk | www.oem.co.uk

*DIDOJATAGO

DATALOGIC - QUICK LINK 100

QL100 QL100 ID-NET T-CONNECTION

- Fast, easy connection for ID-NET™ networks
- Compact dimensions
- Time-saving solution




PRODUCT DESCRIPTION


Quick Link is a complete series for fast, easy cabling of an ID-NET™ network by means of standard cables. QL100/150/200 are slave modules designed for use with the master modules QL300/500 or CBX100/500. Quick Link 100 is a T-connector used in ID-NET™ networks for distributing signals and supply voltage to the reader.

TECHNICAL DATA

IP class	IP65
Power consumption max	4 A
Storage temperature max	70 °C
Storage temperature min	-20 °C
Supply voltage dc max	30 V DC
Supply voltage dc min	10 V DC
Temperature operational max	50 °C
Temperature operational min	0 °C
Weight	115 g




must first be configured for Ethernet communication. This is done by connecting to the sugh: the RS232 Aux port available on the QL500 I/O Port and running the software in program.




ID-NET™ Synchronized Network - DS4800 Master with QL50 + DS4800 Slaves with QL200 and QL100

- The reader must first be configured for Ethernet communication. This is done by connecting to the reader through the RS232 Aux port available on the QL500 I/O Port and running the software configuration program.
- The above diagram is an example showing layout connections and is not intended to represent power limits, which instead, depend on each specific application. See "Voltage Drop and Max Distributed




D-NET™ Synchronized Network - Matrix 400™ Master with QL30




25P D-Su	ider ib Female	
Pin	Function	
1, shell, both bushings	Reader Chassis	13 1
13	Vdc	(000000000000
25	GND	25 14
23	ID+	
24	ID-	
20	RXA	
21	TXA	


	D-NET Out Female (A-coded)	P5
Pin	Function	P4 P1
1	Shield	
2	Vdc	
3	GND	
4	ID+	P3 P2
5	ID-	

	D-NET In Male (A-coded)	P5
Pin	Function	P2 P1
1	Shield	746 V
2	Vdc *	((((((*********************************
3	GND	
4	ID+	P3 P4
5	ID-	






¹ The reader must first be configured for Ethernet communication. This is done by connecting to the reader through the RS232 Aux port available on the QL500 I/O Port and running the software configuration program.




ID-NET™ Synchronized Network - DS4800 Master with QL50
+ DS4800 Slaves with QL200 and QL100

- ¹ The reader must first be configured for Ethernet communication. This is done by connecting to the reader through the RS232 Aux port available on the QL500 I/O Port and running the software configuration program.
- The above diagram is an example showing layout connections and is not intended to represent power limits, which instead, depend on each specific application. See "Voltage Drop and Max Distributes".



ID-NET™ Synchronized Network - Matrix 400™ Master with QL30
+ Matrix 400™ Slaves with QL150



NET™ Multidata Network - DS4800 Master with QL300 + Mixed Reader Slaves with QL300s

Rea 25P D-Su		
Pin	Function	
1, shell, both bushings	Reader Chassis	13 1
13	Vdc	(000000000000
25	GND	25 14
23	ID+	
24	ID-	
20	RXA	
21	TXA	

	D-NET Out Female (A-coded)	P5
Pin	Function	P4 P1
1	Shield	THE STATE OF THE S
2	Vdc	
3	GND	
4	ID+	P3 P2
5	ID-	

